




[2009 Chevrolet Express - AWD](#) | [Express, Savana \(VIN G/H\) Service Manual](#) | [Driver Information and Entertainment](#) | [Secondary and Configurable Customer Controls](#) | [Specifications](#) | **Document ID: 1764524**

Fastener Tightening Specifications

Application	Specification	
	Metric	English
Steering Wheel Trim Plate Screw	2 N·m	18 lb in
Radio Control Screw	2 N·m	18 lb in



Steering Wheel Control Switch Assembly Replacement



Callout	Component Name
Preliminary Procedure	
Remove the inflatable restraint steering wheel module. Refer to Inflatable Restraint Steering Wheel Module Replacement .	
1	Steering Wheel Trim Plate Screw (Qty: 4) Caution: Refer to Fastener Caution in the Preface section. Tighten 2 N·m (18 lb in)
2	Steering Wheel Trim Plate (Qty: 2)
3	Radio Control Screw (Qty: 6) Caution: Refer to Fastener Caution in the Preface section. Tighten 2 N·m (18 lb in)
	Radio Control Switch Assembly

4	Procedure <ol style="list-style-type: none">1. Disconnect the electrical connector.2. Make sure the steering wheel control switches are properly seated to the steering wheel trim cover during installation.
5	Cruise Control Switch Assembly Procedure <ol style="list-style-type: none">1. Disconnect the electrical connector.2. Make sure the steering wheel control switches are properly seated to the steering wheel trim cover during installation.