


[2009 Chevrolet Express - AWD](#) | [Express, Savana \(VIN G/H\) Service Manual](#) | [Driver Information and Entertainment](#) | [Displays and Gages](#) | [Specifications](#) | **Document ID: 1765327**

Fastener Tightening Specifications


Application	Specification	
	Metric	English
Instrument Cluster to Instrument Panel Screws	2 N·m	18 lb in

Ambient Air Temperature Gauge Sensor Replacement



Callout	Component Name
Preliminary Procedure	
Remove the front grill assembly. Refer to Grille Replacement .	
1	Ambient Air Temperature Gauge Sensor Assembly Procedure 1. Unsnap the sensor from the bracket. 2. Disconnect the electrical connection.


Electronic Compass Module Replacement



Callout	Component Name
Preliminary Procedure	
Lower the rear edge of the front headliner to gain access. Refer to Headlining Front Trim Panel Replacement .	
1	Electronic Compass Module Procedure <ol style="list-style-type: none">1. Disconnect the electrical connection.2. Unsnap the module from the headliner assembly.3. For programming and set up procedures, refer to Control Module References.


Multifunction Alarm Module Replacement

Removal Procedure




1. Remove the driver side knee bolster bracket. Refer to [Driver Knee Bolster Bracket Replacement](#) .
2. Disconnect the multifunction audio alarm module (2) electrical connector (1).
3. Remove the multifunction audio alarm module (2) from the vehicle.

Installation Procedure




1. Install the multifunction audio alarm module (2) to the mag beam.
2. Connect the electrical connector (1) to the multifunction audio alarm module (2).
3. Install the driver side knee bolster bracket. Refer to [Driver Knee Bolster Bracket Replacement](#) .

Driver Information Display Switch Replacement



Callout	Component Name
1	Instrument Panel Cluster Trim Plate Bezel Assembly Refer to Instrument Panel Cluster Trim Plate Bezel Replacement .
2	Drivers Information Switch Assembly Procedure Release the retaining tabs on the back of the switch and remove the switch from the cluster trim bezel assembly.

Instrument Cluster Replacement



Callout	Component Name
Preliminary Procedures <ol style="list-style-type: none">1. Remove both drivers and passenger knee bolsters. Refer to Passenger Knee Bolster Replacement and Driver Knee Bolster Replacement.2. Remove the cluster trim plate assembly. Refer to Instrument Panel Cluster Trim Plate Bezel Replacement.	
1	<p>Instrument Panel Cluster Screw (Qty: 3)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tighten 2 N·m (18 lb in)</p>
2	<p>Instrument Panel Cluster Assembly</p> <p>Procedure</p> <ol style="list-style-type: none">1. Disconnect the electrical connections.2. Refer to Control Module References for programming and set up procedures.

© 2010 General Motors Corporation. All rights reserved.